



because clean matters.



SweepZone® Ultrasonic Cleaning Systems



SweepZone 200 shown w/accessories

All SweepZone Ultrasonic Cleaning Systems operate with a special cleaning wave of +/- 2KHz energy that literally sweeps back and forth throughout the ultrasonic tank. The innovative L&R SweepZone technological system incorporates Pulse Width Modulation (PWM), which enables the machines to sense cleaning loads, solution levels and voltage fluctuations.

SweepZone Ultrasonic Cleaning Systems automatically adjust to different conditions in order to create more uniform cleaning power by eliminating hot spots and weak areas in the tank. This results in unsurpassed cleaning performance with every application.

User friendly digital touch pad controls make it easy and convenient to set any of the five preset timer settings from a range of six to sixty minutes. Durable stainless steel housing and tank are corrosion resistant and long lasting.

Product Code	Description	Input Power Average watts 117 VAC 60 Hz	Amps	Overall Dimensions* Inches Centimeters (L x W x H)	Shipping Weight Pounds Kilograms	Tank Capacity Gallons & Liters	Tank Internal Dimensions Inches Centimeters (L x W x D)
AG902	SweepZone 200 w/Timer & Drain, Stainless Steel Cover	100	0.812	12.68 x 6.88 x 8.75 32.2 x 1.75 x 22.2	12 5.4	1.06 4.0	11.75 x 6 x 4 29.8 x 15.2 x 10.2
AG910	SweepZone 310 w/Timer & Drain, Stainless Steel Cover	400	3.419	16.5 x 10 x 12.13 41.9 x 25.4 x 30.5	26 11.8	3.25 12.3	15.5 x 9 x 6 39.4 x 22.9 x 15.2
AG918	SweepZone 1000 w/Timer & Drain, Stainless Steel Cover	500	4.274	17 x 19 x 20 43.2 x 48.3 x 50.8	101 45.8	11.62 44.0	14 x 16 x 10 35.6 x 40.6 x 25.4
AG919	SweepZone 1000 w/Timer, Drain, Heat, Stainless Steel Cover	500	4.274	17 x 19 x 20 43.2 x 48.3 x 50.8	101 45.8	11.62 44.0	14 x 16 x 10 35.6 x 40.6 x 25.4

All systems operate at 43kHz – 45kHz sweep range with a sweep rate of either 3 or 83 Hz. All systems are available with international voltages

All L&R SweepZone Ultrasonic Cleaning Systems are backed by an unprecedented 2 ½ year warranty on parts & labor.



SweepZone 310



SweepZone 1000

Visit our website to see our full line of quality solutions and accessories